



For Technical support, visit us at www.sunsetter.com/ownerscorner
or call Toll Free 1-800-670-7071 * Fax 877-224-4944

Upper Bracket Replacement- Model 900XT & 1000XT

Tools Needed: 7/16" wrench & 3/8" socket and driver

Parts Supplied: Upper bracket & 2 Lag screws (1/4" x 3")

WARNING: Failure to follow these instructions can result in PERSONAL INJURY!! Please read these instructions in its entirety before attempting to complete this process.

PLEASE NOTE THAT LEFT AND RIGHT REFERENCES ARE AS YOU ARE FACING THE HOUSE.

1. Using the hand crank, unroll the awning until the fabric is completely extended. Do not lock the rafters.
2. On the side needing replacement, remove the 1/4" nut and bolt that secures the rafter end to the upper bracket. Carefully fold the rafter set on top of the arm.
3. Remove the two 1/4" lag screws that secure the upper bracket to the house and remove the bracket.
4. Attach the new upper bracket to the house with the two new lag screws.
5. Secure the rafter end to the upper bracket with the 1/4" bolt and nut and tighten with a 7/16" wrench.
6. Test the awning for proper operation.