



For Technical support, visit us at www.sunsetter.com/ownerscorner
or call Toll Free 1-800-670-7071 * Fax 877-224-4944

SunSetter Window Awning Front Bar Replacement Instructions

Helper Needed

Tools Needed: 5mm Allen Wrench

Parts Supplied: Front Bar

WARNING: FAILURE TO FOLLOW THESE INSTRUCTIONS CAN RESULT IN PERSONAL INJURY! PLEASE READ AND FOLLOW THESE INSTRUCTIONS IN THEIR ENTIRETY BEFORE ATTEMPTING TO COMPLETE THE PROCESS.

NOTE: LEFT AND RIGHT REFERENCES ARE AS YOU ARE FACING YOUR AWNING.

STEP 1. Open the awning, and allow the fabric to completely unroll.

STEP 2. Using a helper. Hold the Front Bar and loosen the left Front Bar Insert with a 5mm Allen wrench and pull the insert out of the Front Bar. Repeat for the other side of the awning.

STEP 3. Remove the Front Bar from the fabric.

STEP 4. Insert the new Front Bar into the open end of the fabric and center so that equal amounts of the bar are exposed on either end.

STEP 5. Starting on the left side, slide the Rubber Front bar insert into the front bar. While holding the front bar, tighten the insert using a 5mm Allen wrench. Repeat for the other side of awning.

STEP 6. Pull the awning cord so that the fabric rolls up completely under the Hood Unit, test awning for proper operation.