



For Technical support visit us at www.sunsetter.com/ownerscorner
or call Toll Free 800-670-7071 • Fax 877-224-4944

DeFlappers Installation Instructions

INSTALL THE DEFLAPPERS, TWO PER SIDE, SO THAT THE DEFLAPPERS ARE EQUALLY SPACED BETWEEN THE HOUSE AND THE ROLLER BAR ALONG THE HEM OF FABRIC.

STEP 1. With the knob facing down, and the rubber pads on the awning fabric hem, tighten the knob.

STEP 2. Pull the bungee cord under and around the awning rafter and place over the ball that secures the cord.

STEP 3. Repeat for the remaining three DeFlappers.

WARNING - When leaving the awning open unattended, even with the DeFlappers installed, you must lower one arm or both to create enough drop (front to back) to prevent rain from accumulating on the fabric. If the awning is used with both arms in the vertical position, you must bring at least one arm back to the wall bracket, and then lower it.

