



For Technical support, visit us at www.sunsetter.com/ownerscorner
or call Toll Free 1-800-670-7071 * Fax 877-224-4944

AWNING REMOVAL PROCEDURE

For Model 900XT and 1000XT Only

****HELPER NEEDED****

TOOLS NEEDED:

-Phillips screwdriver
-7/16" Wrench
-3/8" Socket and driver
-Step ladder

PARTS ENCLOSED:

- (2) Cable ties (10" long)

Warning: Failure to wear safety glasses or to follow the instructions below can result in PERSONAL INJURY.

PLEASE NOTE THAT LEFT AND RIGHT REFERENCES ARE AS YOU ARE FACING THE HOUSE.

- STEP 1 Using the hand crank wand roll the awning out 6-12 inches.
- STEP 2 Wrap the cable ties around the left and right arms and loosely secure them above the rafter lock latch.
- STEP 3 Release each arm from the bottom bracket, one at a time, and lower the bottom of each arm to the deck or patio. **You will need to extend the inner arm out, depending on the installed height of the bottom brackets.** Allow the bottom of the arm to sit approximately 2 feet away from the house.

NOTE: YOUR HELPER MAY NEED TO LIFT UP ON THE ARM ASSEMBLY WHILE YOU COMPLETE THE NEXT STEP.

- STEP 4 Remove the Hex-bolt and nut securing the rafter ends to the upper brackets on each side.
- STEP 5 Remove the screws from the upper bracket on each side.
- STEP 6 Remove all screws from the awning rail and allow roller to rest against the house.
- STEP 7 With your helper, lay the awning on the surface of the deck or two chairs.
- STEP 8 Remove the Flat-head cap bolt that secures each arm assembly to the roller bar and slide each arm away from the roller assembly.
- STEP 9 Remove the lower brackets from the wall. This completes the awning removal process.