



For Technical support, visit us at www.sunsetter.com/ownerscorner
or call Toll Free 1-800-670-7071 * Fax 877-224-4944

SunSetter Window Awning Arm Assembly Replacement Instructions

Helper Needed

Tools Needed: 5mm Allen Wrench, Philips screwdriver

Parts Supplied: Left or Right Arm Assembly

WARNING: FAILURE TO FOLLOW THESE INSTRUCTIONS CAN RESULT IN PERSONAL INJURY! PLEASE READ AND FOLLOW THESE INSTRUCTIONS IN THEIR ENTIRETY BEFORE ATTEMPTING TO COMPLETE THE PROCESS.

NOTE: LEFT AND RIGHT REFERENCES ARE AS YOU ARE FACING YOUR AWNING.

STEP 1. With the **Awning completely closed**, remove the bottom pan-head screw that is securing the arm assembly that you are replacing to your house. Save the screw for reuse later in reassembly.

STEP 2. Open the awning, and allow the fabric to completely unroll.

STEP 3. Using a helper. Hold the Front Bar on the side that you are replacing the arm assembly and loosen the Front Bar Insert with a 5mm Allen wrench and pull the insert out of the Front Bar.

STEP 4. As your helper holds the end of the front bar, remove the upper pan-head screw and remove the arm assembly and arm bracket cover from your house.

STEP 5. Slide the Arm Bracket cover over the new Arm Assembly and orient the arm on the wall so that the Rubber Front Bar insert is facing toward the front bar and install the upper pan-head screw.

STEP 6. Slide the Rubber Front bar insert into the front bar. While holding the front bar, tighten the insert using a 5mm Allen wrench.

STEP 7. Pull the awning cord so that the fabric rolls up completely under the Hood Unit, and tie off the cord on the cleat.

STEP 8. Install the bottom pan-head screw into the Arm Assembly.

STEP 9. Test Awning for proper operation.