

RETRACTABLE AWNINGS For Technical Support visit us at www.sunsetter.com/ownerscorner or Call Toll Free 800-670-7071 • Fax 877-224-4944

# **CENTER SUPPORT INSTALLATION INSTRUCTIONS**

Tools Needed: 1/2" Socket and Wrench

Parts Supplied: Center Support and Hardware

## WARNING: FAILURE TO FOLLOW THESE INSTRUCTIONS CAN RESULT IN PERSONAL INJURY

Make sure the awning is completely retracted against the house.

Unplug the power cord from the wall outlet on your house.

## Note: Before proceeding, please familiarize yourself with the components shown in figure 1.

- 1. Slide the Center Support on to the Square Bar, approximately centered between the ends of the two Lateral Arms, BUT NOT directly under the center seam of the Fabric. See Figure 1.
- 2. Install the bolt and washer from the bottom of the Center Support and secure with the provided square Nut. Do Not Tighten the Bolt at This Time.
- 3. With the Center Support installed you should slide the unit along the Square Bar until the pad on the Center Support is next to the side of the Center sewn seam of the Acrylic Awning Fabric.

## <u>Note</u>: The Center Support should not be directly below the seam of the Arcylic Fabric, but to the side.

- 4. Using a  $\frac{1}{2}$ " Socket or Wrench tighten the retaining bolt.
- 5. Plug the power cord into the wall outlet on your house.

<u>CAUTION</u>: Before opening the awning, it is important to be sure that the OPEN stop setting on the motor has not been disturbed. After pressing the OPEN button on the Remote Transmitter to extend the Awning, be ready to press the middle "MY" button (STOP) if the roller bar continues to unroll past the point what the fabric starts to excessively sag. If this happens, press the "CLOSE" button on your remote transmitter to close the awning and refer to the enclosed Appendix to reset the OPEN limit position on your awning.

### WARNING: FAILURE TO FOLLOW THIS INSTRUCTION CAN CAUSE THE FABRIC TO TEAR ON THE CENTER SUPPORT.

6. Test the operation of your Awning by using the OPEN and CLOSE buttons on your Remote Transmitter.

