

For Technical Support visit us at www.sunsetter.com/ownerscorner or Call Toll Free 800-670-7071 • Fax 877-224-4944

Inner Arm Replacement Instructions - Model Model 900/1000 XT

Tools Needed: ¾6" wrench, flat tip screwdriver, and either an 8mm or ¾6" wrench.

Parts Supplied: Inner Arm (Left or Right)

WARNING: FAILURE TO FOLLOW THESE INSTRUCTIONS CAN RESULT IN PERSONAL INJURY!! PLEASE READ THESE INSTRUCTIONS IN ITS ENTIRETY BEFORE ATTEMPTING TO COMPLETE THIS PROCESS.

PLEASE NOTE THAT LEFT AND RIGHT REFERENCES ARE AS YOU ARE FACING THE HOUSE.

- 1. Using the hand crank, unroll the Awning approximately 6-12" from the house.
- 2. On the side needing replacement, unlatch the bottom of the Arm from the Wall Bracket on the house.
- 3. Swing the Arm away from the house.
- 4. If the Inner Arm is configured with the Bolt shown in **Figure 1**, use the 8mm or 5%" wrench to remove it now.
- 5. Operate the Lift Handle and slide the Inner Arm out of the Outer Arm.
- 6. Transfer the Acorn Nut Stop from the old Arm to the new Arm (using the same hole location) and tighten with the $\frac{7}{16}$ " wrench and flat tip screwdriver. See **Figure 2**.
- 7. Operate the Lift Handle and slide the replacement Inner Arm into the Outer Arm until it stops on the Acorn Nut.
- 8. If the original Inner Arm being replaced is configured with the Bolt shown in **Figure 1**, use the 8mm or $\frac{5}{16}$ wrench to tighten it now.
- 9. If the original Inner Arm being replaced does not have the Bolt shown in **Figure 1**, remove this Bolt and discard it.
- 10. Swing the Arm back towards the house and latch the bottom of the Arm into the Wall Bracket.
- 11. Test the Awning for proper operation.



