

## Appearance

Problem	Solution
Fabric rolls up unevenly or pulls to one side when the Motorized EasyShade is being closed.	<ol style="list-style-type: none"><li data-bbox="488 201 1521 275">1. Check the Aluminum Housing to ensure it is mounted level on the mounting surface.</li><li data-bbox="488 285 1521 510">2. It is necessary to have the Guiding Cables completely plumb, up and down. Both the Aluminum Housing and the Cable Brackets must be installed on the same vertical surface or plane, in order for the Fabric to open and close smoothly and evenly. Please check to ensure the Guiding Cable is plumb front to back and left to right. You might need to move the Cable Brackets or shim them to ensure they are located on the same vertical plane.</li></ol>
Short lines appear in the Solar Screen fabric.	Very slight lines in the fabric might be noticed near the top of the Solar Screen. These are caused by clips required to secure the Solar Screen fabric to the internal roller bar. This is normal and should diminish over time, under warm conditions. This might be more pronounced under cool conditions.