



For Technical support, visit us at www.sunsetter.com/ownerscorner
or call Toll Free 1-800-670-7071 * Fax 877-224-4944

SunSetter EasyShade Left End Cap Replacement Instructions

Tools Needed: Phillips Screwdriver

Parts Supplied: Left End Cap

WARNING: FAILURE TO WEAR SAFETY GLASSES OR TO FOLLOW THE INSTRUCTIONS BELOW CAN RESULT IN PERSONAL INJURY!

STEP 1. ON THE END OPPOSITE THE CRANK LOOP, remove the two Phillips screws from the end plate of the EashShade Assembly. Remove the end plate. See Figure 1.



Figure 1

STEP 2 Slide the replacement end cap into the nylon roller cap and secure with the two Phillips screws.

STEP 3. Test the EasyShade panel for proper operation.