



TELESCOPING FLAGPOLES

For Technical Support visit us at www.sunsetter.com/ownerscorner
or Call Toll Free 800-670-7071 • Fax 877-224-4944

Lower Swivel Replacement Instructions

Tools Needed: None

Parts Supplied: Lower Swivel

WARNING: FAILURE TO FOLLOW THESE INSTRUCTIONS CAN RESULT IN PERSONAL INJURY! PLEASE READ THESE INSTRUCTIONS COMPLETELY BEFORE PERFORMING THIS PROCEDURE.

1. Remove the clip from the Lower Swivel.
2. Remove the two top sections of the pole by first lifting Tube #2 until the Spring Button locks. Next, depress the Spring Button and extend Tube #2 completely out of Tube #3.
3. Remove the top section of the pole by holding in the Spring Button and extending the section upwards and out of pole #2. Leave the Double Swivel on Tube #1, being careful to not lose it.
4. Remove the tube #2 Clear Bushing by depressing the two clear tabs while pulling the Clear Bushing up and out of the pole section. Note the alignment of the Clear Bushing.
5. Slide the Lower Swivel off the top of the Tube.
6. Slide the new Lower Swivel over the top of the Tube. The flat side of the Lower Swivel faces up, the curved side faces down.
7. Align and insert the Clear Bushing onto the top of tube #2.
8. Place the two top tubes back into tube #3. Lower them slowly until the button pops out of the hole in tube #3. Be sure to line up the slot in the bottom cap with the track on the inside of the tube.
9. Reinstall the clip removed in step 1.
10. Test the Flagpole for proper operation.

