



## TELESCOPING FLAGPOLES

For Technical Support visit us at [www.sunsetter.com/ownerscorner](http://www.sunsetter.com/ownerscorner)  
or Call Toll Free 800-670-7071 • Fax 877-224-4944

### Tube #2 Bottom Cap Replacement Instructions

**Tools Needed: Phillips Screwdriver**

**Parts Supplied: Tube #2 Bottom Cap, Mounting Screws (qty 2)**

**WARNING: FAILURE TO FOLLOW THESE INSTRUCTIONS CAN RESULT IN PERSONAL INJURY! PLEASE READ THESE INSTRUCTIONS COMPLETELY BEFORE PERFORMING THIS PROCEDURE.**

1. Remove the two top sections of the pole by first lifting tube #2 until the Spring Button locks. Next, depress the Spring Button and extend tube #2 completely out of tube #3.
2. Remove the Bottom Cap mounting screws and remove the Bottom Cap.
3. Align the slot in the new Bottom Cap with the track inside the tube and slide the new Bottom Cap into the tube.
4. Install the two Bottom Cap mounting screws.
5. Place the two top tubes back into tube #3. Lower them slowly until the Spring Button pops out of the hole in tube #3. Be sure to line up the slot in the Bottom Cap with the track on the inside of the tube.
6. Test the Flagpole for proper operation.

