


Platinum Plus Semi-Cassette Awning Parts Diagram









Supplied Fasteners / Parts List

Note: All Awnings ship with one of the following types of Brackets and Mounting Hardware:




Mounting Hardware Includes:

- Two 4" Lag Screws and Flat Washers for each Wall Bracket
- One Retaining Bolt Set for each Wall Bracket




Mounting Hardware Includes:

- One 4" Lag Screw and Flat Washer for each Wall Bracket (use 4" Lag Screw in top Bracket hole)
- One 5" Lag Screw and Flat Washer for each Wall Bracket (use 5" Lag Screw in bottom Bracket hole)
- One Retaining Bolt Set for each Wall Bracket



Mounting Hardware Includes:

- Two 4" Lag Screws and Flat Washers for each Soffit Bracket
- One Retaining Bolt Set for each Soffit Bracket



Additional Parts Supplied

MultiChannel Remote Transmitter, Qty 1

A Spare CR2430 Lithium Battery for the Remote Transmitter is packaged in the clear bubble pack taped to the Motor Power Cord.




CLOSE
my/STOP
OPEN

Channel Indicator Lights
Channel Selector Button

Note: Awning is preset to operate on Channel 1.

- Check the active Channel by briefly pressing the Channel Selector Button. The active Channel Light will blink.
- Change Channel by pressing the Channel Selector Button.
- Press the Channel Selector Button again while the Channel Indicator Light blinks and the next Channel will be selected.



Optional Parts List - Masonry, Brick or Concrete Installations

(available for all models)

3/8" x 6" Masonry Drill Bit, Qty 1 (For Masonry Walls)



14' - 16' Awning = Qty 8 17' - 20' Awning = Qty 12

Note:

For XL Extended Projection Awnings, substitute half of the 4" Masonry Bolts with 5" Masonry Bolts



3/2" x 5" Masonry Bolt (For Masonry Walls)

Other Optional Items Packaged in the Same Tube with your Awning (if purchased with your Awning)

- a. Wireless Wind Sensor
- b. Wireless Wall Switch
- c. All-Weather Remote