



For technical support, visit us at [ownerscorner.sunsetter.com](http://ownerscorner.sunsetter.com)  
or call 800-670-7071, fax 877-224-4944

## SunSetter EasyShade Left End Cap Replacement Instructions

**Tools Needed:** Phillips Screwdriver

**Parts Supplied:** Left End Cap

**WARNING: FAILURE TO WEAR SAFETY GLASSES OR TO FOLLOW THE INSTRUCTIONS BELOW CAN RESULT IN PERSONAL INJURY!**

**STEP 1. ON THE END OPPOSITE THE CRANK LOOP**, remove the two Phillips screws from the end plate of the EashShade Assembly. Remove the end plate. See Figure 1.



Figure 1

**STEP 2** Slide the replacement end cap into the nylon roller cap and secure with the two Phillips screws.

**STEP 3.** Test the EasyShade panel for proper operation.