



## TELESCOPING FLAGPOLES

For Technical Support visit us at [ownerscorner.sunsetter.com](http://ownerscorner.sunsetter.com)  
or Call Toll Free 800-670-7071 • Fax 877-224-4944

### Double Swivel Replacement Instructions

**Tools Needed: Phillips Screwdriver**

**Parts Supplied: Double Swivel (FP012-1)**

**WARNING: THE METAL PARTS COULD HAVE SHARP EDGES. TO PREVENT THE RISK OF INJURY, USE SAFETY GLOVES WHEN REMOVING OR REPLACING PARTS. FAILURE TO DO SO COULD CAUSE PERSONAL INJURY.**

**WARNING: FAILURE TO FOLLOW THESE INSTRUCTIONS CAN RESULT IN PERSONAL INJURY! PLEASE READ THESE INSTRUCTIONS COMPLETELY BEFORE PERFORMING THIS PROCEDURE.**

1. Remove the Gold Ball and/or Eagle from top of the Flagpole, if applicable.
2. Remove the Top Cap and Top Swivel. Two small Phillips screws hold the Top Cap in place. Remove these two screws. The Top Cap and Top Swivel will separate from the Top Section
3. Slide the Double Swivel off the Top Section of the Flagpole.
4. Slide the replacement Double Swivel onto the Top Section of the Flagpole.
5. Replace the Top Swivel, Top Cap and two small Phillips screws.
6. Reattach the Gold Ball and/or Eagle, if applicable.

