




TELESCOPING FLAGPOLES

For Technical Support visit us at www.sunsetter.com/ownerscorner
or Call Toll Free 800-670-7071 • Fax 877-224-4944



Ground Sleeve Locking Collar Replacement Instructions

Tools Needed: Allen Wrench (#6 - 5/64)

Parts Supplied: Locking Collar, Mounting Screws (qty 2)

WARNING: FAILURE TO FOLLOW THESE INSTRUCTIONS CAN RESULT IN PERSONAL INJURY! PLEASE READ THESE INSTRUCTIONS COMPLETELY BEFORE PERFORMING THIS PROCEDURE.

1. Remove the Flagpole from the Ground Sleeve.
2. Remove the two bottom screws from the Locking Collar on the Ground Sleeve.
3. Remove the Locking Collar.
4. Align the new Locking Collar with the holes in the ground sleeve.
5. Secure the new Locking Collar with the two new mounting screws.
6. Test the Flagpole for proper operation.