



TELESCOPING FLAGPOLES

For Technical Support visit us at ownerscorner.sunsetter.com
or Call Toll Free 800-670-7071 • Fax 877-224-4944

Tube #1 Bottom Cap Replacement Instructions

Tools Needed: Phillips Screwdriver

Parts Supplied: Tube #1 Bottom Cap (FP017-1), Mounting Screws (qty 2)

WARNING: THE METAL PARTS COULD HAVE SHARP EDGES. TO PREVENT THE RISK OF INJURY, USE SAFETY GLOVES WHEN REMOVING OR REPLACING PARTS. FAILURE TO DO SO COULD CAUSE PERSONAL INJURY.

WARNING: FAILURE TO FOLLOW THESE INSTRUCTIONS CAN RESULT IN PERSONAL INJURY! PLEASE READ THESE INSTRUCTIONS COMPLETELY BEFORE PERFORMING THIS PROCEDURE.

1. Extend the top section up until the Spring Button pops out. Remove the top section of the Flagpole by holding in the Spring Button while extending the section upwards and out of pole #2.
2. Remove the Bottom Cap mounting screws and remove the Bottom Cap.
3. Align the slot in the Bottom Cap with the rib inside the tube and slide the Bottom Cap into the tube.
4. Install the two Bottom Cap mounting screws.
5. Place tube #1 back into the main tube assembly. Lower it slowly until the Spring Button pops out of the hole in tube #2. Be sure to line up the slot in the Bottom Cap with the track on the inside of the tube.
6. Test the Flagpole for proper operation.

