



TELESCOPING FLAGPOLES

For Technical Support visit us at ownerscorner.sunsetter.com
or Call Toll Free 800-670-7071 • Fax 877-224-4944

Tube #2 Bottom Cap Replacement Instructions

Tools Needed: Phillips Screwdriver

Parts Supplied: Tube #2 Bottom Cap (FP014-1), Mounting Screws (qty 2)

WARNING: THE METAL PARTS COULD HAVE SHARP EDGES. TO PREVENT THE RISK OF INJURY, USE SAFETY GLOVES WHEN REMOVING OR REPLACING PARTS. FAILURE TO DO SO COULD CAUSE PERSONAL INJURY.

WARNING: FAILURE TO FOLLOW THESE INSTRUCTIONS CAN RESULT IN PERSONAL INJURY! PLEASE READ THESE INSTRUCTIONS COMPLETELY BEFORE PERFORMING THIS PROCEDURE.

1. Remove the two top sections of the pole by first lifting tube #2 until the Spring Button locks. Next, depress the Spring Button and extend tube #2 completely out of tube #3.
2. Remove the Bottom Cap mounting screws and remove the Bottom Cap.
3. Align the slot in the new Bottom Cap with the track inside the tube and slide the new Bottom Cap into the tube.
4. Install the two Bottom Cap mounting screws.
5. Place the two top tubes back into tube #3. Lower them slowly until the Spring Button pops out of the hole in tube #3. Be sure to line up the slot in the Bottom Cap with the track on the inside of the tube.
6. Test the Flagpole for proper operation.

