



TELESCOPING FLAGPOLES

For Technical Support visit us at ownerscorner.sunsetter.com
or Call Toll Free 800-670-7071 • Fax 877-224-4944

Tube #4 Clear Bushing Replacement Instructions

Tools Needed: Phillips Screwdriver

Parts Supplied: Clear Bushing (FP023-1)

WARNING: THE METAL PARTS COULD HAVE SHARP EDGES. TO PREVENT THE RISK OF INJURY, USE SAFETY GLOVES WHEN REMOVING OR REPLACING PARTS. FAILURE TO DO SO COULD CAUSE PERSONAL INJURY.

WARNING: FAILURE TO FOLLOW THESE INSTRUCTIONS CAN RESULT IN PERSONAL INJURY! PLEASE READ THESE INSTRUCTIONS COMPLETELY BEFORE PERFORMING THIS PROCEDURE.

1. Remove the top three sections of the pole by holding in the bottom Spring Button and extending the top 3 sections upwards and out of pole #4.
2. Remove the tube #4 Clear Bushing by depressing the two clear tabs while pulling the Clear Bushing up and out of the pole section. Note the orientation of the old Clear Bushing.
3. Align and insert the new Clear Bushing into the tube section.
4. Place the top three tube sections back into the main tube assembly. Lower them slowly until the Spring Button pops out of the hole in tube #4. Be sure to line up the slot in the Bottom Cap with the track on the inside of the tube.
5. Test the Flagpole for proper operation.

